

Grounds Catcher Usage Instructions

Safety: Read First

- Do not use a beaker that is scratched, chipped or cracked – however minor. Install a replacement aerolatte beaker before using the French press again.
- Scald hazard. Not for use by children or those with impaired judgement.
- Plunge gently: excessive plunging force can cause scalding coffee to shoot from the beaker.
- Use only coarse ground coffee.
- Read full instructions before use.

Use the *aerolatte*® Grounds Catcher to make the clean-up of your French press so much quicker and easier, to save your sink and our sewers from blocking up with coffee detritus and to improve your compost or garden by using nutrient rich coffee grounds to improve your plants.

Instructions:

1. Drop the *aerolatte*® Grounds Catcher into the bottom of your glass beaker.
2. Add the coffee and prepare your French press as you would normally
3. When plunging, stop pushing the press when you reach the top of the Grounds Catcher. Do not push it into the grounds catcher yet
4. Pour and drink your coffee as usual.
5. When ready to clean up, pour out any excess coffee so that the French press is dry
6. Push the plunger that little bit further so it engages with the Grounds Catcher.
7. Slowly remove the plunger from the beaker and the Grounds Catcher will come up with it. Allow the remaining liquid to drip back into the pot.
8. Now grab the Grounds catcher with your hand and just twist it off the plunger filter. Empty the grounds catcher into your compost bin or directly onto your plants by just gently tapping it.
9. Rinse out your grounds catcher and your glass beaker.

NB You will find less than a teaspoon of coffee grounds left in your beaker at the end of this process. This is completely needed by